

#### LA-UR-17-30708

Approved for public release; distribution is unlimited.

5 years of research of Differential Die-Away (DDA) Instrument within the Next Generation Safeguards Initiative Title:

Author(s): Henzl, Vladimir

Intended for: presentation to sponsor

Issued: 2017-11-22



# 5 years of research of Differential Die-Away (DDA) Instrument within the Next Generation Safeguards Initiative

### What have we learnt?

Vlad Henzl

NEN-1






# Overview (DDA@NGSI)

- **❖ 2009 14 NDA techniques started** (... not all made it)
- ❖ 2011 NGSI Project merit review DDA almost abandoned
- **❖ 2014** one of the most comprehensive and promising techniques
- ❖ 2015+ design/build of prototype for CLAB, Sweden
- ❖ 15+ people contributed (Pauline Blanc, Stephen Croft, Kiwan Chung, Noah Fisher, Alison Goodsell, Vlad Henzl, Taehoon Lee, Henrik Liljenfeld, Niklas Lundquist, Tomas Martinik, Howard Menlove, Martyn Swinhoe, Steve Tobin, Holly Trellue, Rob Weldon, ...)
- ❖ tested against simulations of 1000+ SFA's (SFL-1, 2a, 2c, 2e, 3, 4, 5, 6)





# Original DDA(+DN) Instrument Design



Design by P. Blanc & H. Menlove

- DDA+DNInstrument Design
  - Stainless steel (SS) as a reflector





UNCLASSIFIED



### DDA response phenomenology (fresh fuel vs. spent fuel)

- Fresh fuel => DDA response increases (die-away time is longer) with increasing fissile content
- Spent fuel => DDA response decreases (die-away time is shorter) with higher burn-up (i.e. more neutron absorbers present)







DDA signal = integral of counts in a given time domain (without the contribution of burst neutrons)



# Charlton & Humphrey JNMM 40(3), 18-23(2012)

#### DDA General Characteristics Time Required for Development Short Portable Cost (High, Med, Low)<sup>g</sup> Н Practical Implementation when Fixed in a Facility Hardware Maturity High Quantification Ability for Assemblies for: Elemental Pu Ν <sup>239</sup>Pu Ν 235L J Ν <sup>241</sup>Pu Ν <sup>240</sup>Pu Ν <sup>239</sup>Pueff Υ Fission product absorbers Ν Other actinide absorbers Ν <sup>239</sup>Pueff Quantification Penetrability (# rows) 9 Ν Burnup Initial Enrichment Ν Ν Cooling Time Pin Diversion Sensitivity (High, Med, Low) in: Μ Outer Region (rows 1-2) Μ Middle Region (rows 3-5) Center Region (rows 6-9) Μ Independence of (for Fissile Mass Quantification): Burnup Ν Ν Initial Enrichment Cooling Time Ν Priority for More Work

# 2014 Status of DDA Internal Review

	DDA
General Characteristics	
Time Required for Development	Short
Portable	Y
Cost (High, Med, Low) <sup>g</sup>	Н
Practical Implementation when Fixed in a Facility	Υ
Hardware Maturity	High
Quantification Ability for Assemblies for:	
Elemental Pu	Y
<sup>239</sup> Pu	Ν
235()	Y
<sup>241</sup> Pu	Ν
<sup>240</sup> Pu	Ν
<sup>239</sup> Pueff	Υ
Fission product absorbers	Υ
Other actinide absorbers	Υ
<sup>239</sup> Pueff Quantification Penetrability (# rows)	9
Burnup	Υ
Initial Enrichment	Υ
CoolingTime	Υ
Pin Diversion Sensitivity (High, Med, Low) in:	
Outer Region (rows 1-2)	М
Middle Region (rows 3-5)	М
Center Region (rows 6-9)	М
Independence of (for Fissile Mass Quantification):	
Burnup	Υ
Initial Enrichment	Υ
Cooling Time	Υ
Priority for More Work	2


# Charlton & Humphrey JNMM 40(3), 18-23(2012)

#### DDA General Characteristics Time Required for Development **Short Portable** Cost (High, Med, Low)<sup>g</sup> Н Practical Implementation when Fixed in a Facility Hardware Maturity High **Quantification Ability for Assemblies for:** Flemental Pu <sup>239</sup>Pu N 235[ ] Ν 241PLL Ν <sup>240</sup>Pu Ν <sup>239</sup>Pueff Fission product absorbers Ν Other actinide absorbers Ν <sup>239</sup>Pueff Quantification Penetrability (# rows) 9 Ν Burnup Ν Initial Enrichment Ν Cooling Time Pin Diversion Sensitivity (High, Med, Low) in: Μ Outer Region (rows 1-2) Μ Middle Region (rows 3-5) Center Region (rows 6-9) Μ Independence of (for Fissile Mass Quantification): Burnup Ν Ν Initial Enrichment Cooling Time Ν Priority for More Work

#### 2014 Status of DDA

• Any instrument that measures multiplication and passive neutrons can determine tot  $m_{Pu}$ 

$$m_{Pu} = a(CT) \frac{M + 2c}{M + c} \left[ \left( \frac{M}{M + 2c} \right) NE \right]^{b(CT)}$$



# Charlton & Humphrey JNMM 40(3), 18-23(2012)


	DDA
General Characteristics	
Time Required for Development	Short
Portable	Ν
Cost (High, Med, Low) <sup>g</sup>	Н
Practical Implementation when Fixed in a Facility	Υ
Hardware Maturity	High
Quantification Ability for Assemblies for:	
Elemental Pu	Ν
<sup>239</sup> Pu	Ν
235(_)	Ζ
<sup>241</sup> Pu	Ν
240p.,	N!
<sup>239</sup> Pueff	Υ
Fission product absorbers	N
Other actinide absorbers	Ν
<sup>239</sup> Pueff Quantification Penetrability (# rows)	9
Burnup	Ζ
Initial Enrichment	Ν
CoolingTime	Ν
Pin Diversion Sensitivity <sup>i</sup> (High, Med, Low) in:	
Outer Region (rows 1-2)	М
Middle Region (rows 3-5)	М
Center Region (rows 6-9)	М
Independence of (for Fissile Mass Quantification):	
Burnup	Ν
Initial Enrichment	Ν
Scoling Time	Z
Priority for More Work	2

#### 2014 Status of DDA


$$^{239}Pu_{eff} = c_1 m(^{235}U) + m(^{239}Pu) + c_2 m(241Pu)$$

### Measurement of <sup>239</sup>Pu<sub>eff DDA</sub> (in time domain 100-200µs)

#### **UNCORRECTED**



#### CORRECTED



let's correct DDA signal by the die-away time

$$CorDDA = DDA(SFA,t) \cdot \tau^{\varepsilon(t)}$$

$$\varepsilon = -2.03$$
 $\sigma = 1.74\%$ 



UNCLASSIFIED




# Charlton & Humphrey JNMM 40(3), 18-23(2012)

	DDA
General Characteristics	
Time Required for Development	Short
Portable	Ν
Cost (High, Med, Low) <sup>§</sup>	Н
Practical Implementation when Fixed in a Facilit	у Ү
Hardware Maturity	High
Quantification Ability for Assemblies for	:
Elemental Pu	Ν
<sup>239</sup> Pu	Ν
235	Ν
<sup>241</sup> Pu	Ν
240PL	N!
<sup>239</sup> Pueff	<b>(</b> Y
Fission product absorbers	N
Other actinide absorbers	Ν
<sup>239</sup> Pueff Quantification Penetrability (# rows)	9
Burnup	Ν
Initial Enrichment	Ν
CoolingTime	Ν
Pin Diversion Sensitivity (High, Med, Low)	in:
Outer Region (rows 1-2)	М
Middle Region (rows 3-5)	М
Center Region (rows 6-9)	М
Independence of (for Fissile Mass Quantificat	tion):
Burnup	N
Initial Enrichment	N
Spoling Time	N
Priority for More Work	2

#### 2014 Status of DDA


$$^{239}Pu_{eff} = c_1 m(^{235}U) + m(^{239}Pu) + c_2 m(^{241}Pu)$$


- DDA signal needs to be corrected by die-away time
- <sup>239</sup>Pu<sub>eff</sub> independent of IE, BU, CT



..what is the meaning of die-away time?

### DDA response & evaluation of neutron absorbers






"effective neutron absorber coefficient":

=> Ratio of DDA signal for fresh fuel (FF) and spent fuel (SFA) for given *M* and given time domain

#### => also reflected by die-away time (!!!)






# Charlton & Humphrey JNMM 40(3), 18-23(2012)

	DDA
General Characteristics	
Time Required for Development	Short
Portable	Ν
Cost (High, Med, Low) <sup>g</sup>	Н
Practical Implementation when Fixed in a Facility	Υ
Hardware Maturity	High
Quantification Ability for Assemblies for:	
Elemental Pu	Ν
<sup>239</sup> Pu	Ν
235()	Ν
<sup>241</sup> Pu	Ν
<sup>240</sup> Pu	Ν
<sup>239</sup> Pueff	Y
Fission product absorbers	N
Other actinide absorbers	N
<sup>239</sup> Pueff Quantification Penetrability (# rows)	9
Burnup	Ν
Initial Enrichment	Ν
CoolingTime	Ν
Pin Diversion Sensitivity <sup>i</sup> (High, Med, Low) in:	
Outer Region (rows 1-2)	М
Middle Region (rows 3-5)	М
Center Region (rows 6-9)	М
Independence of (for Fissile Mass Quantification):	
Burnup	Ν
Initial Enrichment	Ν
CoolingTime	Ν
Priority for More Work	2

#### 2014 Status of DDA

#### effNA = DDAFF/ DDASFA


- effNA effective neutron absorbers
- <u>Die-away time is a measure of</u> neutron absorbers in the SFA




# Charlton & Humphrey JNMM 40(3), 18-23(2012)

#### DDA General Characteristics Time Required for Development **Short Portable** Ν Cost (High, Med, Low)<sup>g</sup> Н Practical Implementation when Fixed in a Facility Hardware Maturity High Quantification Ability for Assemblies for: Flemental Pu Ν <sup>239</sup>Pu Ν 235[ J Ν 241Pu Ν 240Pu Ν <sup>239</sup>Pueff Υ Fission product absorbers Ν Other actinide absorbers Ν <sup>239</sup>Pueff Quantification Penetrability (# rows) 9 Burnup Initial Enrichment Ν Ν **Cooling Time** Pin Diversion Sensitivity (High, Med, Low) in: Μ Outer Region (rows 1-2) Μ Middle Region (rows 3-5) Center Region (rows 6-9) Μ Independence of (for Fissile Mass Quantification): Burnup Ν Initial Enrichment Ν Cooling Time Ν Priority for More Work 2

#### 2014 Status of DDA




$$\tau_{DDA} = a(IE) \cdot DDA + b(IE)$$




# Charlton & Humphrey JNMM 40(3), 18-23(2012)

	DDA
General Characteristics	
Time Required for Development	Short
Portable	Ν
Cost (High, Med, Low) <sup>g</sup>	Н
Practical Implementation when Fixed in a Facility	Υ
Hardware Maturity	High
Quantification Ability for Assemblies for:	
Elemental Pu	Ν
<sup>239</sup> Pu	Ν
235	Ν
<sup>241</sup> Pu	Ν
<sup>240</sup> Pu	Ν
<sup>239</sup> Pueff	Υ
Fission product absorbers	Ν
Other actinide absorbers	Ν
<sup>239</sup> Pueff Ouantification Penetrability (# rows)	9
Burnup	N
Initial Enrichment	N
CoolingTime	Ν
Pin Diversion Sensitivity <sup>i</sup> (High, Med, Low) in:	
Outer Region (rows 1-2)	М
Middle Region (rows 3-5)	М
Center Region (rows 6-9)	М
Independence of (for Fissile Mass Quantification):	
Burnup	Ν
Initial Enrichment	Ν
CoolingTime	Ν
Priority for More Work	2

#### 2014 Status of DDA



#### **BUT**: CT needs to be known




# Charlton & Humphrey JNMM 40(3), 18-23(2012)

		DDA
Ger	neral Characteristics	
Time Required for	Development	Short
Portable		Ν
Cost (High, Med, L	.ow) <sup>g</sup>	Н
Practical Implemen	ntation when Fixed in a Facility	Υ
Hardware Maturity	/	High
Quantification	on Ability for Assemblies for:	
Elemental Pu		Ν
<sup>239</sup> Pu		7
235		7
<sup>241</sup> Pu		Ν
<sup>240</sup> Pu		Ν
<sup>239</sup> Pueff		Υ
Fission product ab	sorbers	Ν
Other actinide abs	orbers	Ν
<sup>239</sup> Pueff Quantifica	tion Penetrability (# rows)	9
Burnup		Ν
Initial Enrichment		N
CoolingTime		N
Pin Diversion	Sensitivity <sup>i</sup> (High, Med, Low) in:	
Outer Region (rov	vs I-2)	М
Middle Region (ro	ws 3-5)	M
Center Region (ro	ws 6-9)	М
Independence of	(for Fissile Mass Quantification):	
Burnup		Ν
Initial Enrichment		N
CoolingTime		Ν
Pric	ority for More Work	2

#### 2014 Status of DDA

#### **Unfinished work**


=> first results promising




# Charlton & Humphrey JNMM 40(3), 18-23(2012)

	DDA
General Characteristics	
Time Required for Development	Short
Portable	Ν
Cost (High, Med, Low) <sup>g</sup>	Н
Practical Implementation when Fixed in a Facility	Υ
Hardware Maturity	High
Quantification Ability for Assemblies for:	
Elemental Pu	Ν
<sup>239</sup> Pu	N
235()	Ν
<sup>241</sup> Pu	Z
<sup>240</sup> Pu	Z
<sup>239</sup> Pueff	Y
Fission product absorbers	Ν
Other actinide absorbers	Ν
<sup>239</sup> Pueff Quantification Penetrability (# rows)	9
Burnup	Ν
Initial Enrichment	Ν
CoolingTime	Ν
Pin Diversion Sensitivity (High, Med, Low) in:	
Outer Region (rows 1-2)	М
Middle Region (rows 3-5)	М
Center Region (rows 6-9)	М
Independence of (for Fissile Mass Quantification):	
Burnup	Ν
Initial Enrichment	Ν
CoolingTime	Ν
Priority for More Work	2

#### October 2014:




# Charlton & Humphrey JNMM 40(3), 18-23(2012)




#### October 2014:

- With fission chambers no Pb shielding needed
- DDA works without tailoring material too




by Niklas Lundkvist


### How to tailor NG neutrons?



 Choice of tailoring material is <u>not</u> very significant









### To tailor or not to tailor?

#### "base" design



"bare" design




- Neutrons entering SFA have energy < 1.0 MeV</li>
- Fast fission on <sup>238</sup>U minimized
- Neutrons entering SFA have energy of <u>14.1 MeV</u>
  - Fast fission on <sup>238</sup>U *maximized*

UNCLASSIFIED

Slide 18

### To tailor or not to tailor?

Any DDA design is evaluated on its ability to determine <sup>239</sup>Pu<sub>eff</sub>




 "Bare" design performs just as well as other designs with tailoring material






# Charlton & Humphrey JNMM 40(3), 18-23(2012)



#### October 2014:


- With fission chambers no Pb shielding needed
- DDA works without tailoring material too




by Niklas Lundkvist


### Role of individual detectors





- SFL2e highly asymmetrically burned SFA's
- BU asymmetry develops when SFA burned on the edge of the reactor core
- Most of SFA's in real world likely have asymmetric BU
- Simulated assay of SFA from 4 sides






UNCLASSIFIED

Slide 21


### Role of individual detectors


- DDA response sensitive to orientation of SFA only for <u>FRONT</u> detectors
- BACK detectors NOT sensitive to SFA orientation

#### front detectors




#### back detectors





SFA's with 4% IE, 15-45 GWd/tU BU, CT=5, 20y (3 different shuffling scenarios)






UNCLASSIFIED

Slide 22


## **Novel DDA designs**

Understanding of DDA opens new possibilities

#### Minimalist DDA



#### Defectoscope DDA










### **DDA Fork detector**

Culmination of NA-22 funded project of experimental verification of DDA "physics" predicted by NA-241 funded simulations



- 2 parts of the instrument
  - NG with Pb shielding
  - 3He/FC detectors & more in a Fork-like configuration
- Portable system for spent fuel pond measurements
- Operated by 1-2 inspectors by the side of the pool
- Full benefits of traditional DDA

UNCLASSIFIED

# **Summary**

### 

	DDA
General Characteristics	
Time Required for Development	Short
Portable	Z
Cost (High, Med, Low) <sup>g</sup>	Н
Practical Implementation when Fixed in a Facility	Υ
Hardware Maturity	High
Quantification Ability for Assemblies for:	
Elemental Pu	Ζ
<sup>239</sup> Pu	Z
235()	Z
<sup>241</sup> Pu	Z
<sup>240</sup> Pu	N
<sup>239</sup> Pueff	Υ
Fission product absorbers	Ν
Other actinide absorbers	Ν
<sup>239</sup> Pueff Quantification Penetrability (# rows)	9
Burnup	Z
Initial Enrichment	Z
CoolingTime	Z
Pin Diversion Sensitivity (High, Med, Low) in:	
Outer Region (rows 1-2)	Μ
Middle Region (rows 3-5)	Μ
Center Region (rows 6-9)	М
Independence of (for Fissile Mass Quantification):	
Burnup	Z
Initial Enrichment	Z
CoolingTime	Z
Priority for More Work	2

### 

	DDA
General Characteristics	
Time Required for Development	Short
Portable	Y
Cost (High, Med, Low) <sup>8</sup>	Н
Practical Implementation when Fixed in a Facility	Υ
Hardware Maturity	High
Quantification Ability for Assemblies for:	
Elemental Pu	Y
<sup>239</sup> Pu	Ν
235	Y
<sup>241</sup> Pu	Ν
<sup>240</sup> Pu	Ν
<sup>239</sup> Pueff	Υ
Fission product absorbers	Υ
Other actinide absorbers	Υ
<sup>239</sup> Pueff Quantification Penetrability (# rows)	9
Burnup	Y
Initial Enrichment	Υ
Cooling Time	Υ
Pin Diversion Sensitivity (High, Med, Low) in:	
Outer Region (rows 1-2)	М
Middle Region (rows 3-5)	М
Center Region (rows 6-9)	М
Independence of (for Fissile Mass Quantification):	
Burnup	Y
Initial Enrichment	Υ
Cooling Time	Υ
Priority for More Work	2